

# SPARK KIT - PARTS LIST

<p>Breadboard</p>  <p>1. ×1</p>	<p>Arduino UNO</p>  <p>2. ×1</p>	<p>Light Emitting Diode (LED)</p>  <p>3. ×15</p>	<p>Buzzer</p>  <p>4. ×2</p>	<p>IR Sensor Module</p>  <p>5. ×2</p>
<p>PIR Sensor Module</p>  <p>6. ×2</p>	<p>Light Dependent Resistor Module</p>  <p>7. ×1</p>	<p>Resistor Box</p>  <p>8. ×1</p>	<p>L293D Module</p>  <p>9. ×1</p>	<p>Servo Motor</p>  <p>10. ×1</p>
<p>Relay Module</p>  <p>11. ×1</p>	<p>Battery &amp; Cap</p>  <p>12. ×2</p>	<p>Jumper wires (all Types)</p>  <p>13. ×3 strips</p>	<p>Chassis and its parts</p>  <p>14. ×1</p>	<p>Transistor BC547</p>  <p>15. ×2</p>
<p>Push Button</p>  <p>16. ×4</p>	<p>Ultrasonic Sensor</p>  <p>17. ×1</p>	<p>LCD</p>  <p>18. ×1</p>	<p>Bulb, holder and wire</p>  <p>19. ×1</p>	<p>7805</p>  <p>20. ×1</p>
<p>1000 uf capacitor</p>  <p>21. ×2</p>	<p>Potentiometer</p>  <p>22. ×1</p>	<p>Keypad</p>  <p>23. ×1</p>	<p>Stepper motor</p>  <p>24. ×1</p>	<p>470 uf capacitor</p>  <p>25. ×2</p>
<p>CD 4081</p>  <p>26. ×1</p>	<p>Double sided tape</p>  <p>27. ×1</p>	<p>RF Module 433 MHz</p>  <p>28. ×1</p>	<p>12v Rechargeable battery</p>  <p>29. ×1</p>	